

#5864RTCA-U - Rear Upper Tubular Control Arm Instructions *for 1958-64 Fullsize Chevrolet Car*

Parts List:

1 ea	Rear Upper Control Arm Assembly
2 ea	5/8-18x4 Bolt
2 ea	5/8-18 Lock Nut
4 ea	5/8 Flat Washer

Instructions:

1. Remove the original upper links.
2. Using the hardware install the new upper link. The curve will be up above the axle housing.

Notes:

Some cars use only one upper link while other cars use two upper links.

Recommendations:

In order to realize the maximum benefits of these arms, CPP recommends using the 5864RTCA-L rear tubular lower control arms with this kit.

GENERAL TORQUE SPECIFICATIONS:

1/4"	grade 5	10lb/ft	1/4"	grade 8	14lb/ft
5/16"	grade 5	19lb/ft	5/16"	grade 8	29lb/ft
3/8"	grade 5	33lb/ft	3/8"	grade 8	47lb/ft
7/16"	grade 5	54lb/ft	7/16"	grade 8	78lb/ft
1/2"	grade 5	78lb/ft	1/2"	grade 8	119lb/ft
9/16"	grade 5	114lb/ft	9/16"	grade 8	169lb/ft
5/8"	grade 5	154lb/ft	5/8"	grade 8	230lb/ft

