In this kit you will find the following:

- 1. Three Main Firewall grommets:
 - a. \mathbf{F} One 1 1/4 inch OD, with a small hole.
 - b. G Two 1 1/4 inch OD, with a large hole.
- 2. Misc. connectors and terminals to complete the Engine Compartment and Passenger Compart ment connections.
- 3. Two wrap around clamps **S**, plus screw, nut and washers **R**, to hold the Main Dash Harness bundle in place.
- 4. Two Door Jamb Switches Y, for the Interior Lighting.

Use these parts to complete the connections from the Main Dash Harness **510554** to the various components in the Engine Compartment and the Passenger Compartment (see Instructions **92970710**).

The 1962 to 1964 Ford Fairlane and the 1962 to 1963 Mercury Meteor had two rectangular holes and one round hole in the upper left corner of the Firewall that allowed wiring to pass through from the Passenger Compartment to the Engine Compartment. You will use these same three holes, and install grommet **F** in the round hole and grommet **G** in the two rectangular holes. The Wiper Wiring will pass through the round hole and the Engine Compartment Wiring will pass through the rectangular holes (see Instructions 92970725).

For the 1965 Fairlane there is only one round hole (install grommet **G**) and one rectangular hole (install grommet **G**). All wiring will pass through these holes (see Instructions 92970725).



www.americanautowire.com 856-933-0801

PART#

510558

DESCRIPTION:

Parts Kit 1962-65 Ford Fairlane 1962-63 Mercury Meteor Classic Update Series

92970729 Rev 1.0

ev 1.0 8/16/201

In the box below, you will find the legend for the misc. terminals, plastic connector bodies, and the main firewall grommets, that will be used to complete your main power, forward lighting, engine, and alternator connections. They are itemized and referred to on this page, just as they are on pages 12 and 13 of the Main Instruction set (92970710) and the Fuse Block Mounting Instructions (92970725).

