

PLEASE NOTE:

This pattern MUST be printed at 100% on 11x17 paper for **correct** pattern trimming.

1955-57 Chevrolet Car Booster Assembly Frame Pattern "A" - Part #5557UPB

Please read ALL instructions that accompany this pattern before use.

This pattern is used for proper frame alignment when installing your power brake booster/master cylinder pedal assembly. For ease of installation, template should be cut along dotted lines from this page.

