



Steering, Brake & Suspension Specialists

#6072TTA - Tubular Trailing Arms Installation Instructions for 1960-72 Trucks

Parts List:

1 ea	Left Trailing Arm
1 ea	Right Trailing Arm

Notes:

This kit is not recommended for 3/4 ton applications.

CPP recommends:

Deluxe trac bar kit (#6572DT-BK)

Rear shock relocation kit (#6372SRK)

Coil spring retainer (#RCR)

Rear C-notch for lowered trucks (#6372CNK)

Center cross member for lowered trucks (#6372LDL)


Billet carrier bearing for 2 piece driveshaft (#CPPCB)

New U-bolts, nuts, coils springs, and shocks are available from CPP

Instructions:

1. Remove the rear shocks.
2. Remove the rear springs from the trailing arm.

3. If the parking brake cables are attached to the trailing arms, remove the parking brake cables from the trailing arm.
4. Remove the trailing arms from the rear axle.
5. Remove the trailing arms from the cross member.
6. Loosely mount the trailing arms to the crossmember. The arms mount so that the tabs for the parking brake cable are outboard and the perch for the spring is to the top.
7. Connect the trailing arms to the rear axle.
8. If the parking brake cables were attached to the trailing arms, connect the parking brake cables.
9. Tighten the forward mounts of the trailing arms.
10. Install the rear springs.
11. Install the rear shocks.



For technical help call Classic Performance Products Monday thru Friday 8:30am to 5:00pm at (714) 522-2000.

Classic Performance Products, Inc. 714.522.2000 | fax 714.522.2500

378 E. Orangethorpe Ave. | Placentia, CA 92870 | www.classicperform.com