

#6774TCA-UK

Tubular Upper Control Arms Installations Instructions

for 1967-69 Camaro & 1968-74 Nova

Parts List:

- 1 ea Left Upper Control Arm Assembly
- 1 ea Right Upper Control Arm Assembly

2. Install the new upper control arm assemblies. CPP recommends using new ball joints (part # FA487) and new bump stops (part# 3773361).
3. Have the car professionally aligned.

Notes:

The ball joint is mounted to the bottom side of the control arm.

Instructions:

1. Remove the original upper control arms.

GENERAL TORQUE SPECIFICATIONS:

1/4"	grade 5	10lb/ft	1/4"	grade 8	14lb/ft
5/16"	grade 5	19lb/ft	5/16"	grade 8	29lb/ft
3/8"	grade 5	33lb/ft	3/8"	grade 8	47lb/ft
7/16"	grade 5	54lb/ft	7/16"	grade 8	78lb/ft
1/2"	grade 5	78lb/ft	1/2"	grade 8	119lb/ft
9/16"	grade 5	114lb/ft	9/16"	grade 8	169lb/ft
5/8"	grade 5	154lb/ft	5/8"	grade 8	230lb/ft

