



*Steering, Brake & Suspension Specialists*

## **#6267SWBK-D - Installation Instructions** *for 1962-67 Chevy II and Nova 2" Drop Spindles*

### **Parts List:**

2 ea	1962-1967 Drop Spindle Assembly
6 ea	Cotter Pins

### **Notes:**

This brake kit is designed to fit 15" or larger wheels.

### **Replacement Parts:**

Brake Rotors, Bearings, & Seals - 1979-81 Chevrolet Chevelle (front)

Brake Calipers, Pads & Hoses - 1982-91 Chevrolet S10 2 wheel drive (front)

### **Instructions:**

1. Safely support the front of the car so that the front tires are off the ground.
2. Remove the front wheels.
3. Working on side of the car at a time, remove the outer tie rod cotter pin and nut from the steering arm.
4. Remove the outer tie rod from the spindle.
5. Remove the upper and lower ball joint cotter pins.
6. Using a floor jack raise the lower control arm just enough to compress the coil spring about an inch. (Make sure the car remains safely on its supports.)
7. Remove the upper ball joint nut and remove the upper ball joint from the spindle.
8. Remove the lower ball joint nut and remove the lower ball joint from the spindle.
9. Set the spindle assembly near by so that the brake hose has no tension on it.
10. Install the lower ball joint onto the new spindle assembly for the appropriate side.
11. Install the upper ball joint and outer tie rod onto the spindle. Install new cotter pins in tie rod end and both ball joints.
12. Remove the original brake hose where it meets the hard line.
13. Connect the new brake hose to the hard line.
14. Discard the original spindle assembly.
15. Repeat steps 3 thru 14 on the opposite side of the car.
16. Bleed the brakes and top off the master cylinder with new brake fluid. Refer to the CPP brake installation guide.
17. Install the front wheels and check that the wheels spin freely.
18. Remove the car from the supports and align the front suspension.

***For technical help call Classic Performance Products Monday thru Friday 8:30am to 5:00pm at (714) 522-2000.***

**Classic Performance Products, Inc. 714.522.2000** | fax 714.522.2500

378 E. Orangethorpe Ave. | Placentia, CA 92870 | [www.classicperform.com](http://www.classicperform.com)