



1955-57 Chevrolet Car Booster Assembly Floorboard Pattern "B" - Part #5557UPB

Please read ALL instructions that accompany this pattern before use.

This pattern is used for proper frame alignment when installing your power brake booster/master cylinder pedal assembly. For ease of installation, template should be cut along dotted lines from this page.

PLEASE NOTE:

This pattern MUST be printed at 100% on 11x17 paper for **correct** pattern trimming.



Classic Performance Products, Inc. **714.522.2000** | FAX 714.522.2500 | 378 E. Orangethorpe Avenue | Placentia, CA 92870 | www.classicperform.com

****1-1/4" tubing, which pedal assembly is connected, lays over frame.**



← **Dimmer Switch Hole**

New Brake Hole →



← **Original Kick Panel**

Floor Seam ↓