



#CPP7401 - Installation Instructions

Rear Sway Bar for 1963-72 Chevy Truck

Instructions:

1. Drill a 7/16" hole thru the side of the frame. This hole will be 20 inches forward of the oval hole above the coil spring and 2 inches above the bottom of the frame.
2. Refer to the illustration as needed.
3. Using a nut and bolt attach the flange to the outside of the frame.
4. Assemble the end links, sway bar and flanges.
5. Coat the sway bar pivot bushing with the supplied grease.
6. Install the pivot bushings on the sway bar. Position the sway bar mounting brackets so that the brackets are under the trailing arms. The sway bar should be centered left to right. The end links should be close to straight up and down.
7. Using the sway bar mounting brackets as a guide drill 3/8" holes thru the bottom flanges of the trailing arm. There should be 1 hole on each side of the center spine of the trailing arm. Attach the mounting brackets with the nuts and bolts.
8. Install the grease fittings into the sway bar mounting brackets.
9. Be sure to road test the truck so you can familiarize yourself with the truck's new handling characteristics.

detail view of bottom of trailing arm



For technical help call Classic Performance Products Monday thru Friday 8:30am to 5:00pm at (714) 522-2000.

Classic Performance Products, Inc. 714.522.2000 | fax 714.522.2500
378 E. Orangethorpe Ave. | Placentia, CA 92870 | www.classicperform.com